

SAMPLE BOARD SET INSTALLATION INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE SAMPLE BOARDS.

Sample Board Set Installation

1. Unpack all materials. Each set includes a left rail, a right rail, and 11 acrylic boards. You will need to provide screws (and possibly anchors) best suited to your wall material.
2. Identify the left rail by the holes as pictured below. Identify the right rail with slots as pictured below.
3. Place the rails at the desired height on your wall. Width between rails should be 25 1/8" from mounting hole to mounting hole.
4. Before securing the rails to the wall, insert a board to test fit. Modify distance between rails, if needed. Then, secure rails with hardware best to your wall material.
5. To attach acrylic boards, place the pin on the left side of the board into the hole in the left rail. Next slide the pin on the right side of the board into the slot on the right rail. This system allow rails to easily to mounted and unmounted, as needed.

