

N E X T

G E N E R A T I O N

I R O N CEILING BRACKET MOUNTING INSTRUCTIONS

1. LOOSEN SMALL SET SCREW USING THE SMALL HEX KEY TOOL PROVIDED AND DISASSEMBLE CEILING BRACKETS.
2. SLIDE BRACKET MOUNTING PLATES INTO TOP CHANNEL ON THE ROD.
3. MEASURE AND ALIGN ALL MOUNTING PLATES ON THE TOP OF THE ROD. (WE RECOMMEND MOUNTING THE END BRACKETS APPROX. 3" FROM THE END OF THE ROD.) SPACE OUT CENTER BRACKETS EVENLY.
4. TIGHTEN BUTTON HEAD SCREWS USING LARGE HEX KEY INCLUDED.
5. MEASURE AND MARK BRACKET LOCATIONS ON THE CEILING. MOUNT WALL PLATES ON THE CEILING USING THE WALL PLATE SCREWS AND DRYWALL ANCHORS.
6. SLIDE COVER PLATE OVER WALL PLATE AND SECURE WITH THREADED POST. TIGHTEN POST WITH PLIERS.
7. SLIDE POST INTO BRACKET AND TIGHTEN SET SCREW WITH SMALL HEX KEY TOOL.

