

WOOD

Hardware



WOOD HARDWARE INSTALLATION INSTRUCTIONS

Note: We recommend installation of drapery hardware by a professional installer.

Hardware included

- 1- Curtain Rod
- 2- Finials
- 2- End Brackets
- 4- 1.5" Bracket screws
- 4- Drywall anchors
- 2- 1" Wood screw
- 4- Wood plugs
- Center Bracket(s) and hardware will be included with rod sets over 72"

Tools required for installation

- Tape Measure
- Drill Motor
- Level
- Phillips Screwdriver
- Pencil

Bracket screws

Drywall anchors

Wood screw

Wood plugs

Bracket



PLEASE READ ALL STEPS PRIOR TO INSTALLING ROD SET

Step 1- If installing a multi-segment rod, first connect wood rod segments together before mounting brackets.

NOTE: The height of your brackets are determined by the length of your window treatments.

Step 2- Thread bracket screws into bracket until the tips of the screws stick out approximately 1/8" (**PIC #1**)

Step 3- Hold the bracket with cup facing up (See **PIC #1**). Use a level on the side of the bracket while placing the bracket on the wall in the desired location. Press firmly on the bracket using the screws to mark the holes.

Step 4- Hold bracket firmly in desired location and use drill motor to tighten screws (use drywall anchors if there is no backing behind drywall). **NOTE:** Bracket holes are made with a slight angle to allow room for screwdriver to tighten screws.

Step 5- If installing center bracket(s), find the center point between end brackets and repeat steps 3 & 4. After all brackets are mounted to the wall, press wood plugs in holes to hide the bracket screws. (**PIC #2**)

Step 6- Slide rings (if applicable) onto wood rod. Center wood rod over the window and secure rod to brackets using 1" wood screw. (**PIC #3**)

Step 7- Attach finials to the ends of your drapery rod.

